

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Questions or Comments? We'd love to help with any questions or concerns. Phone: 1-866-387-8065

Email: info@northridge-home.com

If you prefer, you may also contact us via our website:

www.northridge-home.com

Important Safety Information


- Please read all instructions carefully before assembling this furniture.
- For your safety, assembly by two or more adults is strongly recommended.
- Use only vendor-supplied hardware to assemble this item. Using unauthorized hardware could jeopardize the structural integrity of the item.
- Hardware may loosen over time. Periodically check that all connections are tight.

Before Assembly


- Remove all parts and hardware from the box. Place all items on a carpeted or scratch-free work surface, as this will avoid damaging parts during assembly
- The shipping box provides an ideal work surface.
- To avoid accidentally discarding small parts or hardware, do not dispose or any packaging or contents of the shipping carton until assembly is complete.
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The use of power tools for assemble is not recommended Power tools can damage the hardware and/or split the wood.
- Note Do not fully tighten all bolts until all parts are in place. Failure to follow these instructions may cause the bolts to misalign during assembly.

Care and Cleaning


- Spot clean with upholstery shampoo foam from a mild detergent or mild dry cleaning.
- Do not saturate with liquid.
- Pile fabrics may require brushing to restore appearance.




Components




Step 1



To remove the back, use a screwdriver pressing outward on the back tab in the receiver on both sides and lift the back from the base



Step 3



Completed

